

## Application Note: Hydroxyl Number in Polyols

The use of polymeric polyols is commonplace in the manufacturing of polyurethanes and other specialty polymers. The hydroxyl number (OH#) is a measure of the concentration of the hydroxyl groups on the polyol. This is an important parameter to monitor and control during polyol production. The laboratory method that is commonplace for hydroxyl number determination is both time consuming and involves the use of hazardous materials. This note will discuss the use of Guided Wave hardware and software tools for the measurement of hydroxyl number in polyols using fiber optic-based, Near-Infrared (NIR) spectroscopy. NIR can be applied in real time directly in process or as a laboratory procedure. In either case NIR is a time and money saving alternative to traditional methods. NIR also offers the benefit of increased safety over traditional methods.

### Measurement Background

The NIR region of the electromagnetic spectrum allows the use of the overtone and combination bands of the C-H, O-H, and N-H fundamentals. By measuring the NIR spectra of a series of polyol samples of known hydroxyl number, a quantitative model can be developed which will allow the measurement of hydroxyl number in future samples based only on their NIR spectrum. Guided Wave analyzer systems use fiber optics to allow the sample probe to be located in remote locations away from the spectrometer itself.




Figure 1: NIR Spectra of Polyether Polyol Samples

### Experimental

The NIR spectra of a group of different process polyether polyol samples were measured between 1000 and 1600 nm using a Guided Wave Model 412 NIR Spectrometer. Figure 1 shows the absorbance spectra of some representative samples using an on-line process probe with a 1 cm pathlength. The hydroxyl number for these samples ranges from 9 to 44. For this application, data preprocessing consisted of a simple 2-point baseline correction to remove any offset. The spectra and concentration data were submitted to the Unscrambler™ software and a calibration model was developed using PLS regression methodology. For a discussion of PLS and other multivariate calibration techniques please see Martens & Naes<sup>1</sup> and ASTM E1655<sup>2</sup>.

### Analyzer Selection

For well established process measurements, a Guided Wave ClearView® db multi-wavelength photometer can be used to achieve similar results. The photometer systems offer robust measurement capability for a more focused set of applications. Visit the Guided Wave website for guidance on the choice between measurement systems.

# Application Note: Hydroxyl Number in Polyols

## Results

The model was used to predict hydroxyl number values in a laboratory setting. The results are shown in Figure 2 as a scatter plot. The model produced a RMSEP (root mean square error of prediction) of 1.8. This is in good agreement with the accuracy of the standard laboratory method.

## Conclusion

The measurement of OH number of polyols using NIR spectroscopy is both fast and reliable utilizing the Guided Wave hardware and software tools as described here. This method minimizes the need for performing the previous laboratory method and hence the results are available in real-time (seconds). This method can be applied in a batch reactor system for control of this important property during mixing and to determine the endpoint of the reaction thus resulting in significant savings of time and material costs. For more detailed information regarding system specifications please contact a Guided Wave technical sales specialist.

## References

1. H. Martens, T. Naes, Multivariate Calibration, John Wiley & Sons, 1989.
2. ASTM E1655 Standard Practices for Infrared, Multivariate, Quantitative Analysis.




Figure 2: OH Number Laboratory vs. NIR



Guided Wave ClearView db Photometer



Guided Wave Model 412 NIR Spectrometer